

# Hunter Xci Foil – Wall Assembly Guide Summary

Per Chapter 26 of the International Building Code, the wall assembly shall be tested in accordance with and comply with the acceptance criteria of NFPA 285. The listed assemblies in this document have met that criteria.

<b>I BASE WALL SYSTEM</b>	<b>Steel Stud</b> — 1 layer 5/8" thick Type X Gypsum wallboard on interior, installed over steel studs: minimum 3 5/8" depth, minimum 22 gauge at a maximum of 24 inch o.c. with lateral bracing every 4 ft. vertically.
<b>II CLADDING FAMILY TYPE</b>	<p><b>Masonry</b> — Brick veneer anchors, standard types, installed maximum 24 inches o.c. vertically. Maximum 2 inch air gap between exterior insulation and brick. Standard nominal 4 inch thick or greater, clay brick.</p> <p><b>Limestone or Natural Stone</b> — Minimum 2" thick, Limestone or Natural Stone Veneer. Any standard non-open joint installation technique can be used.</p> <p><b>Cultured Stone</b> — Minimum 1½" thick complying with ICC-ES AC51. Any non-open joint installation technique such as shiplap may be used. Any non-open joint installation technique or ventilated shiplap may be used.</p> <p><b>Stucco</b> — Minimum ¾" thick, Exterior Cement Plaster and Lath.</p>
<b>III MATERIAL OPTIONS</b>	4" max thickness of Hunter <b>Xci Foil</b>
<b>IV FLOORLINE FIRESTOPPING</b>	Mineral fiber based safing insulation in each cavity at floor line. Safing thickness must match cavity depth. OR Solid FRTW blocking at floor line in accordance with building code requirements for Type III construction.
<b>V STUD CAVITY</b>	Any noncombustible insulation, Covestro BaySeal CC X or CC CP <sup>1,2</sup> , BASF Walltite <sup>1,2</sup> , NCFI InsulBlock SPF <sup>1,2</sup> , Icynene MD-C-200v3 (ProSeal) up to 5½ <sup>1,2</sup> , SWD Urethane Quik-Shield 112 <sup>1,2</sup> , 1.5" minimum Thermoseal 2000 (up to full cavity) <sup>2</sup> , or None
<b>VI EXTERIOR SHEATHING</b>	<p>1) ½" (min) thick exterior gypsum sheathing OR ½" (min) FRTW structural panels in Type III construction<sup>1</sup></p> <p>2) USG Securock Exoair 430 System.<sup>3</sup></p>
<b>VII WEATHER RESISTIVE MEMBRANE APPLIED TO BASE WALL</b>	<p>1) None</p> <p>2) Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech NP, Fire Resist Barritech VP (or VP LT)</p> <p>3) CCW-705<sup>1</sup> with 702 LV, 702 WB, Cav-Grip, Low VOC Travel-Tack</p> <p>4) GE Momentive SEC 2500 SilShield, Elemax 2600</p> <p>5) Vaproshield Wrapshield SA, RevealShield SA</p> <p>6) WR Grace Perm-A-Barrier VPS, Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier NPL 10<sup>1</sup>, Perm-A-Barrier VPL 50<sup>1</sup></p> <p>7) StoGuard Vaporseal, Sto Gold Coat or Emerald Coat</p> <p>8) 3M 3015</p> <p>9) Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR and Air-Bloc 16MR, Blueskin VP 160</p> <p>10) DuPont Tyvek CommercialWrap or CommercialWrap D</p> <p>11) PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex<sup>1</sup></p> <p>12) Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP</p> <p>13) Dryvit Backstop NT</p> <p>14) Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx</p> <p>15) WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR</p> <p>16) BASF Enershield HP or Enershield I</p> <p>17) Soprema Sopreseal Stick VP, Soprasolin HD, LM 204 VP</p> <p>18) Pecora XL Perm Ultra VP</p> <p>19) Siga Majvest or Majvest 500 SA</p> <p>20) Tremco ExoAir 230 or ExoAir 130</p> <p>21) Fortifiber Building Systems Group Weather Smart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial, Super Jumbo Tex 60</p>
<b>VIII WEATHER RESISTIVE MEMBRANE APPLIED TO EXTERIOR INSULATION</b>	<p>1) None</p> <p>2) Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech VP, Fire Resist Barritech NP</p> <p>LT, Fire Resist Barritech NP</p> <p>3) GE Momentive SEC 2500 SilShield</p> <p>4) Vaproshield Wrapshield SA, RevealShield SA</p> <p>5) WR Grace Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier VPS</p> <p>6) Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR, Air-Bloc 16MR, Blueskin VP 160</p> <p>7) DuPont Tyvek CommercialWrap</p> <p>8) PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex<sup>1</sup></p> <p>9) Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP</p> <p>10) Dryvit Backstop NT</p> <p>11) Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx</p> <p>12) Sto Gold Coat</p> <p>13) WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR</p> <p>14) Soprema Sopreseal Stick VP, Soprasolin HD</p> <p>15) Pecora XL Perm Ultra VP</p> <p>16) Siga Majvest</p> <p>17) Fortifiber Building Systems Group WeatherSmart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial</p>

[1]Contact Hunter Panels for details regarding this option [2]Can only be used with ½" or greater Gypsum Sheathing [3]When this is used, do not use WRB on base wall surface.

The location and number of WRBs in the wall assembly are determined by the architect.