



HUNTER

XCI PLY AND XCI PLY CLASS A CONCRETE MASONRY WALL

Per Chapter 26 of the International Building Code, the wall assembly shall be tested in accordance with and comply with the acceptance criteria of NFPA 285. The listed assemblies in this document have met that criteria.

NFPA 285 WALL ASSEMBLY GUIDE SUMMARY

I BASE WALL SYSTEM	Concrete Masonry Wall
II CLADDING FAMILY TYPE	<p>Masonry—Brick veneer anchors, standard types, installed maximum 24" o.c. vertically. Maximum 2" air gap between exterior insulation and brick. Standard nominal 4" thick or greater, clay brick.</p> <p>Thin Brick, Cultured Stone—Set in thin set adhesive and metal lath that has been tested to and passed the ASTM E 119 standards or passed NFPA 285 at 3/4" minimum.</p> <p>TABS Panel II System—1/2" thick bricks using TABS Wall Adhesive. Glen Gery - Thin Tech Elite.</p> <p>Limestone or Natural Stone—Minimum 2" thick Limestone or Natural Stone Veneer. Any standard non-open joint installation technique can be used.</p> <p>Stone Aluminum—Stone Aluminum Honeycomb Composite Panels that have been successfully tested by the panel manufacturer via the NFPA 285 test method. Any standard installation technique can be used.</p> <p>Cast Artificial Stone—Minimum 1 1/2" thick complying with ICC-ES AC51. Any non-open joint installation technique such as shiplap may be used.</p> <p>Fiber Cement Porcelain, Ceramic Tile—Minimum 1/4" thickness. Any standard installation technique can be used.</p> <p>Terra Cotta Cladding—Use any Terra Cotta Cladding System in which Terra Cotta is minimum 1/2". Any non-open joint installation technique or ventilated shiplap may be used.</p> <p>Autoclaved Aerated Concrete—AAC panels that have successfully passed NFPA 285 criteria.</p> <p>Metal Exterior—Metal Exterior wall coverings such as Steel, Aluminum, Copper and Zinc (Zinc with Class A only). Any standard installation technique can be used.</p> <p>MCM System—Use any Metal Composite Material system that has been successfully tested by the panel manufacturer via the NFPA 285 test method. Any standard installation technique can be used.</p> <p>Stucco—Minimum 1/2" thick, Exterior Cement Plaster and Lath.</p> <p>HPL—FunderMax m.look minimum 1/4" thick using any standard installation technique.</p>
III MATERIAL OPTIONS	<ol style="list-style-type: none"> 4.2" max thickness of Hunter Xci Ply and Xci Ply Class A, inclusive of factory adhered 5/8" or 3/4" Fire Treated Plywood within overall max thickness 4.7" max thickness of Hunter Xci Ply and Xci Ply Class A, inclusive of factory adhered 5/8" or 3/4" Fire Treated Plywood within overall max thickness with non-combustible claddings
IV FLOORLINE FIRESTOPPING	Not Applicable
V STUD CAVITY	Not applicable
VI EXTERIOR SHEATHING	Not applicable

¹Contact Hunter Panels for details regarding this option.

The location and number of WRBs in the wall assembly are determined by the architect.

VII WEATHER RESISTIVE MEMBRANE APPLIED TO BASE WALL

1. None
2. Hunter Panels Xci VP-SA WRB
3. Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech NP, Fire Resist Barritech VP (or VP LT)
4. GE Momentive SEC 2500 SilShield, Elemax 2600
5. Vaproshield Wrapshield SA, RevealShield SA
6. WR Grace Perm-A-Barrier VPS, Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier NPL 10¹, Perm-A-Barrier VPL 50¹
7. StoGuard Vaporseal, Sto Gold Coat or Emerald Coat
8. 3M 3015
9. Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR and Air-Bloc 16MR, Blueskin VP 160
10. DuPont Tyvek CommercialWrap, CommercialWrap D, StuccoWrap Fluid Applied WB¹
11. PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex¹
12. Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP
13. Dryvit Backstop NT
14. Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx, Delta Stratus SA
15. WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR, Air-Shield SMP
16. BASF Enershield HP or Enershield I
17. Soprema Sopreseal Stick VP, Soprasolin HD, LM 204 VP, Stick 1100T¹
18. Pecora XL Perm Ultra VP, XL Perm Ultra NP, ProPerm VP
19. Siga Majvest or Majvest 500 SA
20. Tremco ExoAir 230 or ExoAir 130
21. Fortifiber WeatherSmart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial, Super Jumbo Tex 60
22. USG Securock Exoair 430 System
23. 5/8" Georgia Pacific DensElement flashed with Prosoco R-Guard FastFlash on sheathing joints
24. Dow Corning DefendAir 200 (or LT version) or DefendAir 200C (charcoal)
25. Hohmann & Barnard Enviro Barrier and Enviro Barrier VP
26. STS FW100 or FW100A
27. Karnak 321 K-NRG
28. NaturaSeal AirSeal NS-A-250LP, AirSeal NS-A-250HP
29. Jumpstart HWW-65A, HWW-65B, HWHP-80A, HWMP-90A, HWD2-72A, HWHPT-92A, HWMPC-105A
30. Master Wall Rollershield
31. Parex WeatherSeal Spray & Roll-On

VIII WEATHER RESISTIVE MEMBRANE APPLIED TO EXTERIOR INSULATION

Hunter Xci recommends a vapor permeable barrier over Xci Ply and Xci Ply Class A. The barriers listed here are approved for NFPA 285 compliance but include options outside of the recommended permeance range. Please contact Hunter Xci for more details.

1. Hunter Panels Xci VP-SA WRB
2. Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech VP, Fire Resist Barritech VP LT, Fire Resist Barritech NP
3. GE Momentive SEC 2500 SilShield
4. Vaproshield Wrapshield SA, RevealShield SA
5. WR Grace Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier VPS
6. Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR, Air-Bloc 16MR, Blueskin VP 160
7. DuPont Tyvek CommercialWrap or StuccoWrap
8. PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex¹
9. Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP
10. Dryvit Backstop NT
11. Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx
12. Sto Gold Coat, Emerald Coat
13. WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR, Air-Shield SMP
14. Soprema Sopreseal Stick VP, Soprasolin HD
15. Pecora XL Perm Ultra VP, XL Perm Ultra NP, ProPerm VP
16. Siga Majvest
17. Fortifiber WeatherSmart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial
18. Dow Corning DefendAir 200 (or LT version) or DefendAir 200C (charcoal)
19. Hohmann & Barnard Enviro Barrier VP
20. STS FW100A
21. Karnak 321 K-NRG
22. Jumpstart HWW-65A, HWW-65B, HWHP-80A, HWMP-90A, HWD2-72A, HWHPT-92A, HWMPC-105A
23. Master Wall Rollershield
24. Parex WeatherSeal Spray & Roll-On

¹ Contact Hunter Panels for details regarding this option.

The location and number of WRBs in the wall assembly are determined by the architect.

CONTINUOUS INSULATION

15 Franklin Street ■ Portland, Maine 04101 ■ 888.746.1114 ■ info@hpanels.com ■ www.hunterpanels.com