



Hunter Xci Foil (Class A) and Xci 286 – Wall Assembly Guide Summary

Per Chapter 26 of the International Building Code, the wall assembly shall be tested in accordance with and comply with the acceptance criteria of NFPA 285. The listed assemblies in this document have met that criteria.

I BASE WALL SYSTEM	Concrete Wall (cast in place or precast)
II CLADDING FAMILY TYPE	<p>Masonry—Brick veneer anchors, standard types, installed maximum 24 inches o.c. vertically. Maximum 2 inch air gap between exterior insulation and brick. Standard nominal 4 inch thick or greater, clay brick.</p> <p>Thin Brick, Cultured Stone—Set in thin set adhesive and metal lath that has been tested to and passed the ASTM E119 standards or passed NFPA 285 at ¾" minimum.</p> <p>TABS Panel II System—½" thick bricks using TABS Wall Adhesive. Glen Gery - Thin Tech Elite.</p> <p>Limestone or Natural Stone—Minimum 2.0" thick, Limestone or Natural Stone Veneer. Any standard non-open joint installation technique can be used.</p> <p>Stone Aluminum—Stone Aluminum Honeycomb Composite Panels that have been successfully tested by the panel manufacturer via the NFPA 285 test method. Any standard installation technique can be used.</p> <p>Cast Artificial Stone—Minimum 1½" thick complying with ICC-ES AC51. Any non-open joint installation technique such as shiplap may be used.</p> <p>Fiber Cement Porcelain, Ceramic Tile—Minimum 1/4" thickness. Any standard installation technique can be used.</p> <p>Terra Cotta Cladding—Use any Terra Cotta Cladding System in which Terra Cotta is minimum ½". Any non-open joint installation technique or ventilated shiplap may be used.</p> <p>Autoclaved Aerated Concrete—AAC panels that have successfully passed NFPA 285 criteria.</p> <p>Metal Exterior—Metal Exterior wall coverings such as Steel, Aluminum, Copper and Zinc (Zinc with Class A only). Any standard installation technique can be used.</p> <p>MCM System—Use any Metal Composite Material system that has been successfully tested by the panel manufacturer via the NFPA 285 test method. Any standard installation technique can be used.</p> <p>Stucco—Minimum ½" thick, Exterior Cement Plaster and Lath.</p> <p>HPL—FunderMax m.look minimum 1/4" thick using any standard installation technique.</p>
III MATERIAL OPTIONS	<ol style="list-style-type: none"> 1) 3.5" max thickness of Hunter Xci Foil (Class A) or Hunter Xci 286 2) 4" max thickness of Hunter Xci Foil (Class A) or Hunter Xci 286 with non-combustible claddings¹
IV FLOORLINE FIRESTOPPING	Not applicable
V STUD CAVITY	Not applicable
VI EXTERIOR SHEATHING	Not applicable

¹Contact Hunter Panels for details regarding this option.



Hunter Xci Foil (Class A) and Xci 286 – Wall Assembly Guide Summary

Per Chapter 26 of the International Building Code, the wall assembly shall be tested in accordance with and comply with the acceptance criteria of NFPA 285. The listed assemblies in this document have met that criteria.

VII WEATHER RESISTIVE MEMBRANE APPLIED TO BASE WALL

- 1) None
- 2) Hunter Panels Xci VP-SA WRB
- 3) Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech NP, Fire Resist Barritech VP (or VP LT)
- 4) CCW-705¹ with 702 LV, 702 WB, Cav-Grip, Low VOC Travel-Tack
- 5) GE Momentive SEC 2500 SilShield, Elemax 2600
- 6) Vaproshield Wrapshield SA, RevealShield SA
- 7) WR Grace Perm-A-Barrier VPS, Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier NPL 10¹, Perm-A-Barrier VPL 50¹
- 8) StoGuard Vaporseal, Sto Gold Coat or Emerald Coat
- 9) 3M 3015
- 10) Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR, Air-Bloc 16MR, Blueskin SA¹, Blueskin VP 160
- 11) DuPont Tyvek CommercialWrap, CommercialWrap D, or StuccoWrap
- 12) PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex¹
- 13) Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP
- 14) Dryvit Backstop NT
- 15) Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx, Delta Stratus SA
- 16) WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR, Air-Shield SMP
- 17) BASF Enershield HP or Enershield I
- 18) Soprema Sopreseal Stick VP, Soprasolin HD, LM 204 VP, Stick 1100T¹
- 19) Pecora XL Perm Ultra VP, XL Perm Ultra NP, ProPerm VP
- 20) Siga Majvest or Majvest 500 SA
- 21) Tremco ExoAir 230 or ExoAir 130
- 22) Fortifiber WeatherSmart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial, Super Jumbo Tex 60
- 23) USG Securock Exoair 430 System
- 24) 5/8" Georgia Pacific DensElement flashed with Prosoco R-Guard FastFlash on sheathing joints
- 25) Dow Corning DefendAir 200 (or LT version) or DefendAir 200C (charcoal)
- 26) Hohmann & Barnard Enviro Barrier and Enviro Barrier VP
- 27) STS FW100 or FW100A
- 28) Karnak 321 K-NRG
- 29) NaturaSeal AirSeal NS-A-250LP, AirSeal NS-A-250HP
- 30) Jumpstart HWW-65A, HWW-65B, HWHP-80A, HWMP-90A, HWD2-72A, HWHPT-92A, HWMPC-105A
- 31) Master Wall Rollershield
- 32) Parex WeatherSeal Spray & Roll-On

VIII WEATHER RESISTIVE MEMBRANE APPLIED TO EXTERIOR INSULATION

- 1) None
- 2) Hunter Panels Xci VP-SA WRB
- 3) Carlisle Fire Resist 705 RS, Fire Resist Barrithane VP, Fire Resist 705 VP, Fire Resist 705 FR-A, Fire Resist Barritech VP, Fire Resist Barritech VP LT, Fire Resist Barritech NP
- 4) GE Momentive SEC 2500 SilShield
- 5) Vaproshield Wrapshield SA, RevealShield SA
- 6) WR Grace Perm-A-Barrier NPL, Perm-A-Barrier VPL, Perm-A-Barrier Aluminum Wall Membrane, Perm-A-Barrier VPL LT, Perm-A-Barrier VPS
- 7) Henry Air-Bloc 17MR, Air-Bloc 21S, Air-Bloc 31MR, Air-Bloc 33MR, Air-Bloc 16MR, Blueskin VP 160
- 8) DuPont Tyvek CommercialWrap or StuccoWrap
- 9) PolyGuard Air Lok Flex VP, FlexGuard, Air Lok Flex¹
- 10) Prosoco R-Guard Cat 5, R-Guard Cat 5 Rainscreen, R-Guard VB or R-Guard Spray Wrap MVP
- 11) Dryvit Backstop NT
- 12) Cosella Dorken Delta-Vent SA, Delta-Vent S, Delta-Fassade S, Delta-Maxx
- 13) Sto Gold Coat
- 14) WR Meadows Air-Shield LMP (Gray or Black), Air-Shield TMP, Air-Shield LSR, Air-Shield SMP
- 15) Soprema Sopraseal Stick VP, Soprasolin HD
- 16) Pecora XL Perm Ultra VP, XL Perm Ultra NP, ProPerm VP
- 17) Siga Majvest
- 18) Fortifiber WeatherSmart Housewrap, WeatherSmart Drainable, WeatherSmart Commercial
- 19) Dow Corning DefendAir 200 (or LT version) or DefendAir 200C (charcoal)
- 20) Hohmann & Barnard Enviro Barrier VP
- 21) STS FW100A
- 22) Karnak 321 K-NRG
- 23) Jumpstart HWW-65A, HWW-65B, HWHP-80A, HWMP-90A, HWD2-72A, HWHPT-92A, HWMPC-105A
- 24) Master Wall Rollershield
- 25) Parex WeatherSeal Spray & Roll-On

¹Contact Hunter Panels for details regarding this option.

The location and number of WRBs in the wall assembly are determined by the architect.